

How to clean

Tools: A soft microfiber cloth or synthetic microfiber chamois. **Cleaning Agents:** Soap Solution (mild soap, detergent, non-abrasive dishwashing soap).

Note: DO NOT use glass cleaning products (these will damage ASTARIGLAS®)

Steps:

1. Remove the dust and dirt off of the surface of ASTARIGLAS[®] - avoid using your hand or a dry cloth as this may scratch the surface of the sheet. Instead, use compressed air or a blower.

2. Once as much dirt has been removed as possible, rinse down the sheet with water to remove the remaining dirt.

3. With diluted soapy water and a soft microfiber cloth, gently wipe down the surface of the sheet. Rinse thoroughly and dry with a clean microfibre cloth.

Note: DO NOT allow sheet to air dry as water spots will remain. Do not use paper towels as they may be abrasive enough scratch the surface and over time, cause the sheet to become cloudy.

How to disinfect

Tools: Soft microfiber cloth or synthetic microfiber chamois and a spray bottle.

Disinfectants: Hand Sanitiser (any brand), Iso Propyl Alcohol (70% solution), Hydrogen Peroxide (3-5% solution), bleach (any brand, please follow recommended dilution ratio).

Steps:

- 1. Wear disposable gloves when disinfecting surfaces.
- 2. Apply chosen disinfectant to surface
- 3. Allow to sit for 10-15 minutes.
- 4. Use microfiber cloth to wipe clean.

mulfordplastics.co.nz

MULFORD P L A S T I C S delivering solutions